

Assembly is the same for all frame shapes & sizes


## Assembly



1. Make sure loop velcro on graphic "endcaps" flap is not attached to hook velcro on frame. Grasp back of frame and expand slowly, pulling frame upright. Adjustable feet indicate the bottom of the frame.




2. Connect all frame locks.



3. Wrap fabric graphic "endcap" flap around side of frame and connect to velcro on frame.




Attach each optional LED light to top "X" of frame.




## Closing the Frame

1. Unhook side endcap velcro from frame (Only the vertical strips on the endcap flaps, leave the rest of the graphic attached to frame).
2. Unlock ALL LOCKS. Failure to disengage all hooks will cause frame damage when collapsing frame.
3. Slowly collapse frame. If you feel resistance, double-check to make sure all hooks are unlocked.


**DO NOT FORCE FRAME CLOSED.**



## Attaching Graphic to the Frame



Expand frame outward on its back. Lock all locks.



Starting on one top corner, secure the graphic onto the frame by attaching the velcroed piece of the graphic onto the frame's velcro strip. Repeat on bottom edge, working the same direction.  
Note: Adjustable feet indicate bottom of frame.

